



**INSTRUCTIONS FOR LOADING AND FIRING  
MASTER BLASTER LAUNCHER  
WITH SINGLE CO2 TRIGGER**

1. Remove cap from one end of plastic speed load tube.
2. Pour contents of plastic speed load tube (confetti) into the barrel of the launcher. The launcher should be filled to within two inches of the top. (Load either 1 - 18" tube of confetti or 2 -9" tubes of confetti into the launcher to get the proper effect.)
3. Place cardboard compression cap over the mouth of the launcher. Using the launcher tape, take a 5" - 6" strip and tape around the outside diameter, being careful to tape smoothly so there are no air bubbles. **DO NOT tape across the top of the cap.**
4. Be sure the lever on the trigger is in the **HORIZONTAL POSITION**. Insert 1 - 8 gram Co2 cylinder into the brass-piercing unit at the bottom of the launcher barrel. **(NOTE – If you are shooting off our 2" X 40' long streamers use 1 – 16 gram Co2 cylinder.)**

Screw the Co2 cylinder to puncture and seal the Co2 into the trigger unit. You may hear gas releasing as you screw in the Co2. If you do, continue screwing the cup in rapidly until it is tightly screwed in and no Co2 is being released. The Co2 cylinder will feel cold in your hand.

5. Point the launcher up and at a slight angle. **(If you are firing CORKSCREWS aim the launcher straight up into the air to get the correct spiraling effect as it flutters and floats into the air.)** Turn the lever on the trigger with one swift motion **COUNTER CLOCK WISE** until it is in the vertical position. The confetti will discharge out of the launcher into a wonderful display of color and fun!

**NOTE – DO NOT POINT OR AIM THIS LAUNCHER TOWARD ANYONE.**

**IF YOU ARE RENTING THE MASTER BLASTER PLEASE KEEP THE BOX IT IS SHIPPED IN SO YOU CAN RETURN IT TO US AT THE FOLLOWING ADDRESS: 5555 65<sup>th</sup> Way North, St. Petersburg, Florida 33709.  
Phone number 727-541-6463.**

**If you have any questions contact us at 877-321-1999 (o) or 504-251-8531 (cell).**

