



INSTRUCTIONS FOR LOADING AND FIRING
HELD LAUNCHER QUARTER TURN LAUNCHER

LOADING THE LAUNCHER

1. Remove the cap from the speed load tube of Flutter Fetti products.
2. Pour the contents (confetti or streamer products) into the barrel of the launcher. The launcher should be filled to within two inches of the top. (Load either 1 - 18" tube of product or 2 -9" tubes of product into the launcher to get the proper effect.)
3. Place cardboard compression cap over the mouth of the launcher.
4. Using the launcher tape, take a 5" - 6" strip and tape around the outside diameter, being careful to tape smoothly so there are no air bubbles. **DO NOT tape across the top of the cap.**

FIRING THE LAUNCHER

5. Be sure the lever on the trigger (the brass knob) is in the horizontal position. Screw on 1 - 8 gram Co2 cylinder into the brass-piercing unit at the bottom of the launcher barrel. You may hear gas releasing as you screw in the Co2. If you do, continue screwing rapidly until it is tightly screwed in and no Co2 is being released. If it is not screwed in tightly the launcher **WILL NOT WORK!**
6. Point the launcher up and at a slight angle. (If you are firing CORKSCREWS aim the launcher straight up into the air to get the correct spiraling effect as it flutters and floats into the air.) Quickly turn the trigger counter clock-wise with one swift motion. The confetti will discharge out of the launcher into a wonderful display of color and fun!

PLEASE NOTE - The Co2 cylinder will ice over upon discharge. Wait a few seconds until it is warm enough to unscrew and discard.

Never point the launcher at or towards anyone. Remember safety first and fun forever!

Please call us toll free at 877-321-1999 to discuss any of the instructions above.

NOTE - IF YOU ARE RENTING THESE LAUNCHERS PLEASE SAVE THE BOX THEY WERE SHIPPED IN TO RETURN THEM TO US.

OUR RETURN ADDRESS IS: Parti Line International 5555 65th Way North St. Petersburg, Florida 33709 Phone number 727-541-6463

