



## INSTRUCTIONS FOR USE X6 CONFETTI LAUNCHER

### LOADING THE LAUNCHER BARRELS

**Step 1** - Put the gray foam lifting seal into the barrels using the loading stick and push the lifting seal all the way to the bottom of the barrels.

**Step 2**- Remove the caps from both ends of the speed load tubes filled with confetti and streamer products. **NOTE** - We recommend filling the launchers with either 2-18" Speed Load tubes of products or 4-9" Speed Load tubes of product.

**Steps 3** - Using the loading stick push contents of the speed load tube into the barrels of the launcher.

**Step 4**- Place the cardboard compression cap over the mouth of the barrels.

**Step 5** -Using the launcher tape, take a 5" - 6" strip and tape around the outside diameter, being careful to tape smoothly so there are no air bubbles. **DO NOT** tape across the top of the cap.

### FIRING THE LAUNCHERS

**Step 6**- Lift the levers on the quick connect coupler on the launching unit. Insert the barrels into the quick connect coupler. Push down on the quick release levers locking the barrel into the proper position. Double-check the connectors so that they are securely fastened and locked

**Step 7** - Screw in the 16 gram threaded Co2 cylinder. Keep screwing quickly until the cylinder is cold. **NOTE**- Screw in the Co2 as close to Showtime as possible.

**Step 8**- Plug in the control switch (red box) to the AC power source. Check that the control switch is OFF. Attach the electric cord to the launcher unit.

**(Continue with these instructions if hanging the X6 from a lighting grid)**

**Steps 9** - Using a wrench loosen the fittings before aiming the barrels. If you are hanging the X6 from a lighting grid first position the launcher in the direction you want the barrels to fire. Next tighten the C-clamp onto the lighting grid so

the barrels point in the correct position. Tighten all fittings after aiming the barrels.

**Step 10** – Next fasten the silver safety strap around the launcher and the lighting grid. If you are ready to fire and are not using a control box, just plug the launcher in and it will fire. If you are using a control box go to step 10.

**(Instructions for using the X6 on a stage floor or hanging from a lighting grid)**

**Step 11-** Turn the control switch on the red box to ON. Verify that the indicator light is on. NOTE- if you are not using a control box then the launchers will fire when they are plugged in.

**Step 12-** When ready to launch push the black firing button.

NOTE- The X6 Launchers can also be turned over and they will sit on a stage floor. When in the sitting position you will need to remove the straight coupling and put in a 45 degree coupling to enable the launcher barrel to be in a 45 degree angle. **We have already done this for you.**

**Please do not hesitate to call us toll free at 877-321-1999 to discuss any of the above.**

**PLEASE DO NOT KEEP THE X-6'S PLUGGED IN. ONLY PLUG THEM IN WHEN YOU ARE READY TO FIRE THEM OFF.**

**CAUTION - DO NOT AIM OR POINT THE LAUNCHER BARRELS AT ANYONE.**

**NOTE - IF YOU ARE RENTING THE X6 PLEASE SAVE THE BOX YOU RECEIVED IT IN SO YOU CAN USE IT TO SHIP THE LAUNCHER BACK TO US.**

**ALSO, IF YOU BREAK ANY PIECES OF THE LAUNCHER PLEASE LET US KNOW. THANK YOU.**